

## Flying Monkey Live Resin - Rainbow Mystery 2.5g Disposable

Sample ID: SA-251021-71193  
 Batch: BATCH: #FMV5LR25-01 | EXP: 10/30/2027  
 Type: Finished Product - Inhalable  
 Matrix: Concentrate - Vape  
 Unit Mass (g):

Received: 10/22/2025  
 Completed: 11/10/2025

**Client**  
 Lost Distribution  
 8 The Green, Suite A  
 Dover, DE 19901  
 USA



### Summary

| Test              | Date Tested | Status |
|-------------------|-------------|--------|
| Cannabinoids      | 11/04/2025  | Tested |
| Foreign Matter    | 10/24/2025  | Tested |
| Heavy Metals      | 10/29/2025  | Tested |
| Microbials        | 10/31/2025  | Tested |
| Mycotoxins        | 11/07/2025  | Tested |
| Pesticides        | 11/10/2025  | Tested |
| Residual Solvents | 10/28/2025  | Tested |

|                 |               |                    |                   |                     |                                 |
|-----------------|---------------|--------------------|-------------------|---------------------|---------------------------------|
| <b>0.0789 %</b> | <b>48.2 %</b> | <b>85.6 %</b>      | <b>Not Tested</b> | <b>Not Detected</b> | <b>Yes</b>                      |
| Total Δ9-THC    | Δ9-THCP       | Total Cannabinoids | Moisture Content  | Foreign Matter      | Internal Standard Normalization |

### Cannabinoids by HPLC-PDA and GC-MS/MS

| Analyte             | LOD (%) | LOQ (%) | Result (%)    | Result (mg/g) |
|---------------------|---------|---------|---------------|---------------|
| CBC                 | 0.0095  | 0.0284  | ND            | ND            |
| CBCA                | 0.0181  | 0.0543  | ND            | ND            |
| CBCV                | 0.006   | 0.018   | ND            | ND            |
| CBD                 | 0.0081  | 0.0242  | 0.309         | 3.09          |
| CBD A               | 0.0043  | 0.013   | ND            | ND            |
| CBDP                |         |         | 0.368         | 3.68          |
| CBDV                | 0.0061  | 0.0182  | ND            | ND            |
| CBDVA               | 0.0021  | 0.0063  | ND            | ND            |
| CBG                 | 0.0057  | 0.0172  | ND            | ND            |
| CBGA                | 0.0049  | 0.0147  | ND            | ND            |
| CBL                 | 0.0112  | 0.0335  | ND            | ND            |
| CBLA                | 0.0124  | 0.0371  | ND            | ND            |
| CBN                 | 0.0056  | 0.0169  | 0.361         | 3.61          |
| CBNA                | 0.006   | 0.0181  | ND            | ND            |
| CBNP                |         |         | 0.134         | 1.34          |
| CBT                 | 0.018   | 0.054   | 0.0654        | 0.654         |
| Δ4,8-iso-THC        | 0.0067  | 0.02    | 0.125         | 1.25          |
| Δ8-iso-THC          | 0.0067  | 0.02    | 0.274         | 2.73          |
| Δ8-THC              | 0.0104  | 0.0312  | 33.9          | 339           |
| Δ8-THCP             |         |         | 1.27          | 12.7          |
| Δ8-THCV             | 0.0067  | 0.02    | 0.457         | 4.57          |
| Δ9-THC              | 0.0076  | 0.0227  | 0.0789        | 0.789         |
| Δ9-THCA             | 0.0084  | 0.0251  | ND            | ND            |
| Δ9-THCP             |         |         | 48.2          | 482           |
| Δ9-THCV             | 0.0069  | 0.0206  | ND            | ND            |
| Δ9-THCVA            | 0.0062  | 0.0186  | ND            | ND            |
| exo-THC             | 0.0067  | 0.02    | ND            | ND            |
| <b>Total Δ9-THC</b> |         |         | <b>0.0789</b> | <b>0.789</b>  |
| <b>Total</b>        |         |         | <b>85.6</b>   | <b>856</b>    |



Generated By: Ryan Bellone  
 Commercial Director  
 Date: 11/13/2025



## Flying Monkey Live Resin - Rainbow Mystery 2.5g Disposable

Sample ID: SA-251021-71193

Batch: BATCH: #FMV5LR25-01 | EXP: 10/30/2027

Type: Finished Product - Inhalable

Matrix: Concentrate - Vape

Unit Mass (g):

Received: 10/22/2025

Completed: 11/10/2025

**Client**Lost Distribution  
8 The Green, Suite A  
Dover, DE 19901  
USA

ND = Not Detected; NR = Sample matrix interference present which may affect accuracy of results; NT = Not Tested; UA = Unsuitable for Analysis; NR = (Spike) Not Recoverable; LOD = Limit of Detection; LOQ = Limit of Quantitation; RL = Reporting Limit;  $\Delta$  = Delta; Total  $\Delta 9$ -THC =  $\Delta 9$ -THCA \* 0.877 +  $\Delta 9$ -THC; Total CBD = CBDA \* 0.877 + CBD;

Generated By: Ryan Bellone  
Commercial Director  
Date: 11/13/2025Tested By: Scott Caudill  
Laboratory Manager  
Date: 11/04/2025ISO/IEC 17025:2017 Accredited  
Accreditation #108651



KCA Laboratories  
232 North Plaza Drive  
Nicholasville, KY 40356

+1-833-KCA-LABS  
<https://kcalabs.com>  
KDA Lic.# P\_0058

## Certificate of Analysis

3 of 8

### Flying Monkey Live Resin - Rainbow Mystery 2.5g Disposable

Sample ID: SA-251021-71193

Batch: BATCH: #FMV5LR25-01 | EXP: 10/30/2027

Type: Finished Product - Inhalable

Matrix: Concentrate - Vape

Unit Mass (g):

Received: 10/22/2025

Completed: 11/10/2025

#### Client

Lost Distribution

8 The Green, Suite A

Dover, DE 19901

USA

### Heavy Metals by ICP-MS

| Analyte | LOD (ppm) | LOQ (ppm) | Result (ppm) |
|---------|-----------|-----------|--------------|
| Arsenic | 0.002     | 0.02      | ND           |
| Cadmium | 0.001     | 0.02      | ND           |
| Lead    | 0.002     | 0.02      | ND           |
| Mercury | 0.012     | 0.05      | ND           |

ND = Not Detected; NT = Not Tested; UA = Unsuitable for Analysis; NR = Sample matrix interference present which may affect accuracy of results; LOD = Limit of Detection; LOQ = Limit of Quantitation; P = Pass; F = Fail; RL = Reporting Limit; Values over action limits may be estimates

Generated By: Ryan Bellone  
Commercial Director  
Date: 11/13/2025

Tested By: Chris Farman  
Scientist  
Date: 10/29/2025



This product or substance has been tested by KCA Laboratories using validated testing methodologies and an ISO/IEC 17025:2017 accredited quality system. Values reported relate only to the product or substance tested. The reported result is based on a sample weight. Unless otherwise stated, results of tests performed on all quality control samples met criteria for acceptance established by KCA Laboratories. KCA Laboratories makes no claims as to the efficacy, safety or other risks associated with any detected or non-detected amounts of any substances reported herein. This Certificate of Analysis shall not be reproduced except in full, without the written approval of KCA Laboratories. KCA Laboratories can provide measurement uncertainty upon request.

## Flying Monkey Live Resin - Rainbow Mystery 2.5g Disposable

Sample ID: SA-251021-71193  
 Batch: BATCH: #FMV5LR25-01 | EXP: 10/30/2027  
 Type: Finished Product - Inhalable  
 Matrix: Concentrate - Vape  
 Unit Mass (g):

Received: 10/22/2025  
 Completed: 11/10/2025

**Client**  
 Lost Distribution  
 8 The Green, Suite A  
 Dover, DE 19901  
 USA

### Pesticides by LC-MS/MS and GC-MS/MS

| Analyte              | LOD (ppb) | LOQ (ppb) | Result (ppb) | Analyte                 | LOD (ppb) | LOQ (ppb) | Result (ppb) |
|----------------------|-----------|-----------|--------------|-------------------------|-----------|-----------|--------------|
| Abamectin            | 30        | 100       | ND           | Hexythiazox             | 30        | 100       | ND           |
| Acephate             | 30        | 100       | ND           | Imazalil                | 30        | 100       | ND           |
| Acetamiprid          | 30        | 100       | ND           | Imidacloprid            | 30        | 100       | ND           |
| Aldicarb             | 30        | 100       | ND           | Kresoxim methyl         | 30        | 100       | ND           |
| Azoxystrobin         | 30        | 100       | ND           | Malathion               | 30        | 100       | ND           |
| Bifenazate           | 30        | 100       | ND           | Metalaxyl               | 30        | 100       | ND           |
| Bifenthrin           | 30        | 100       | ND           | Methiocarb              | 30        | 100       | ND           |
| Boscalid             | 30        | 100       | ND           | Methomyl                | 30        | 100       | ND           |
| Captan               | 30        | 100       | NR           | Mevinphos               | 30        | 100       | ND           |
| Carbaryl             | 30        | 100       | ND           | Myclobutanil            | 30        | 100       | ND           |
| Carbofuran           | 30        | 100       | ND           | Naled                   | 30        | 100       | ND           |
| Chloranthraniliprole | 30        | 100       | ND           | Oxamyl                  | 30        | 100       | ND           |
| Chlordane            | 30        | 100       | NR           | Paclobutrazol           | 30        | 100       | ND           |
| Chlorfenapyr         | 30        | 100       | ND           | Parathion methyl        | 30        | 100       | NR           |
| Chlorpyrifos         | 30        | 100       | ND           | Pentachloronitrobenzene | 30        | 100       | NR           |
| Clofentezine         | 30        | 100       | ND           | Permethrin              | 30        | 100       | ND           |
| Coumaphos            | 30        | 100       | ND           | Phosmet                 | 30        | 100       | ND           |
| Cyfluthrin           | 30        | 100       | NR           | Piperonyl Butoxide      | 30        | 100       | ND           |
| Daminozide           | 30        | 100       | ND           | Prallethrin             | 30        | 100       | ND           |
| Diazinon             | 30        | 100       | ND           | Propiconazole           | 30        | 100       | ND           |
| Dichlorvos           | 30        | 100       | ND           | Propoxur                | 30        | 100       | ND           |
| Dimethoate           | 30        | 100       | ND           | Pyrethrins              | 30        | 100       | ND           |
| Dimethomorph         | 30        | 100       | ND           | Pyridaben               | 30        | 100       | ND           |
| Ethoprophos          | 30        | 100       | ND           | Spinetoram              | 30        | 100       | ND           |
| Etofenprox           | 30        | 100       | ND           | Spinosad                | 30        | 100       | ND           |
| Etoxazole            | 30        | 100       | ND           | Spiromesifen            | 30        | 100       | ND           |
| Fenhexamid           | 30        | 100       | ND           | Spirotetramat           | 30        | 100       | ND           |
| Fenoxycarb           | 30        | 100       | ND           | Spiroxamine             | 30        | 100       | ND           |
| Fenpyroximate        | 30        | 100       | ND           | Tebuconazole            | 30        | 100       | ND           |
| Fipronil             | 30        | 100       | ND           | Thiacloprid             | 30        | 100       | ND           |
| Flonicamid           | 30        | 100       | ND           | Thiamethoxam            | 30        | 100       | ND           |
| Fludioxonil          | 30        | 100       | ND           | Trifloxystrobin         | 30        | 100       | ND           |

ND = Not Detected; NT = Not Tested; UA = Unsuitable for Analysis; NR = Sample matrix interference present which may affect accuracy of results; LOD = Limit of Detection; LOQ = Limit of Quantitation; P = Pass; F = Fail; RL = Reporting Limit; Values over action limits may be estimates



Generated By: Ryan Bellone  
 Commercial Director  
 Date: 11/13/2025



Authorized By: Scott Caudill  
 Laboratory Manager  
 Date: 11/10/2025



## Flying Monkey Live Resin - Rainbow Mystery 2.5g Disposable

Sample ID: SA-251021-71193

Batch: BATCH: #FMV5LR25-01 | EXP: 10/30/2027

Type: Finished Product - Inhalable

Matrix: Concentrate - Vape

Unit Mass (g):

Received: 10/22/2025

Completed: 11/10/2025

**Client**

Lost Distribution

8 The Green, Suite A

Dover, DE 19901

USA

## Mycotoxins by LC-MS/MS

| Analyte      | LOD (ppb) | LOQ (ppb) | Result (ppb) |
|--------------|-----------|-----------|--------------|
| B1           | 1         | 5         | ND           |
| B2           | 1         | 5         | ND           |
| G2           | 1         | 5         | ND           |
| Ochratoxin A | 1         | 5         | ND           |

ND = Not Detected; NT = Not Tested; UA = Unsuitable for Analysis; NR = Sample matrix interference present which may affect accuracy of results; LOD = Limit of Detection; LOQ = Limit of Quantitation; P = Pass; F = Fail; RL = Reporting Limit; Values over action limits may be estimates



 Generated By: Ryan Bellone  
 Commercial Director

Date: 11/13/2025



 Tested By: Chris Farman  
 Scientist

Date: 11/07/2025





## Flying Monkey Live Resin - Rainbow Mystery 2.5g Disposable

Sample ID: SA-251021-71193

Batch: BATCH: #FMV5LR25-01 | EXP: 10/30/2027

Type: Finished Product - Inhalable

Matrix: Concentrate - Vape

Unit Mass (g):

Received: 10/22/2025

Completed: 11/10/2025

**Client**

Lost Distribution

8 The Green, Suite A

Dover, DE 19901

USA


## Microbials by PCR and Plating

| Analyte                              | LOD (CFU/g) | Result (CFU/g) | Result (Qualitative)    |
|--------------------------------------|-------------|----------------|-------------------------|
| Total aerobic count                  | 10          | ND             |                         |
| Aspergillus flavus                   | 1           |                | Not Detected per 1 gram |
| Aspergillus fumigatus                | 1           |                | Not Detected per 1 gram |
| Aspergillus niger                    | 1           |                | Not Detected per 1 gram |
| Aspergillus terreus                  | 1           |                | Not Detected per 1 gram |
| Bile-tolerant gram-negative bacteria | 10          | ND             |                         |
| Total coliforms                      | 10          | ND             |                         |
| Generic E. coli                      | 10          | ND             |                         |
| Salmonella spp.                      | 1           |                | Not Detected per 1 gram |
| Shiga-toxin producing E. coli (STEC) | 1           |                | Not Detected per 1 gram |
| Total yeast and mold count (TYMC)    | 10          | ND             |                         |

ND = Not Detected; NT = Not Tested; UA = Unsuitable for Analysis; NR = Sample matrix interference present which may affect accuracy of results; LOD = Limit of Detection; LOQ = Limit of Quantitation; CFU = Colony Forming Units; P = Pass; F = Fail; RL = Reporting Limit



 Generated By: Ryan Bellone  
 Commercial Director  
 Date: 11/13/2025



 Tested By: Sara Cook  
 Laboratory Technician  
 Date: 10/31/2025


## Flying Monkey Live Resin - Rainbow Mystery 2.5g Disposable

Sample ID: SA-251021-71193  
 Batch: BATCH: #FMV5LR25-01 | EXP: 10/30/2027  
 Type: Finished Product - Inhalable  
 Matrix: Concentrate - Vape  
 Unit Mass (g):

Received: 10/22/2025  
 Completed: 11/10/2025

**Client**  
 Lost Distribution  
 8 The Green, Suite A  
 Dover, DE 19901  
 USA


## Residual Solvents by HS-GC-MS

| Analyte               | LOD (ppm) | LOQ (ppm) | Result (ppm) | Analyte                  | LOD (ppm) | LOQ (ppm) | Result (ppm) |
|-----------------------|-----------|-----------|--------------|--------------------------|-----------|-----------|--------------|
| Acetone               | 167       | 500       | ND           | Ethylene Oxide           | 0.5       | 1         | ND           |
| Acetonitrile          | 14        | 41        | ND           | Heptane                  | 167       | 500       | ND           |
| Benzene               | 0.5       | 1         | ND           | n-Hexane                 | 10        | 29        | ND           |
| Butane                | 167       | 500       | ND           | Isobutane                | 167       | 500       | ND           |
| 1-Butanol             | 167       | 500       | ND           | Isopropyl Acetate        | 167       | 500       | ND           |
| 2-Butanol             | 167       | 500       | ND           | Isopropyl Alcohol        | 167       | 500       | ND           |
| 2-Butanone            | 167       | 500       | ND           | Isopropylbenzene         | 167       | 500       | ND           |
| Chloroform            | 2         | 6         | ND           | Methanol                 | 100       | 300       | ND           |
| Cyclohexane           | 129       | 388       | ND           | 2-Methylbutane           | 10        | 29        | ND           |
| 1,2-Dichloroethane    | 0.5       | 1         | ND           | Methylene Chloride       | 20        | 60        | ND           |
| 1,2-Dimethoxyethane   | 4         | 10        | ND           | 2-Methylpentane          | 10        | 29        | ND           |
| Dimethyl Sulfoxide    | 167       | 500       | ND           | 3-Methylpentane          | 10        | 29        | ND           |
| N,N-Dimethylacetamide | 37        | 109       | ND           | n-Pentane                | 167       | 500       | ND           |
| 2,2-Dimethylbutane    | 10        | 29        | ND           | 1-Pentanol               | 167       | 500       | ND           |
| 2,3-Dimethylbutane    | 10        | 29        | ND           | n-Propane                | 167       | 500       | ND           |
| N,N-Dimethylformamide | 30        | 88        | ND           | 1-Propanol               | 167       | 500       | ND           |
| 2,2-Dimethylpropane   | 167       | 500       | ND           | Pyridine                 | 7         | 20        | ND           |
| 1,4-Dioxane           | 13        | 38        | ND           | Tetrahydrofuran          | 24        | 72        | ND           |
| Ethanol               | 167       | 500       | ND           | Toluene                  | 30        | 89        | ND           |
| 2-Ethoxyethanol       | 6         | 16        | ND           | Trichloroethylene        | 3         | 8         | ND           |
| Ethyl Acetate         | 167       | 500       | ND           | Xylenes (o-, m-, and p-) | 73        | 217       | ND           |
| Ethyl Ether           | 167       | 500       | ND           |                          |           |           |              |
| Ethylbenzene          | 3         | 7         | ND           |                          |           |           |              |

ND = Not Detected; NT = Not Tested; UA = Unsuitable for Analysis; NR = Sample matrix interference present which may affect accuracy of results; LOD = Limit of Detection; LOQ = Limit of Quantitation; P = Pass; F = Fail; RL = Reporting Limit; Values over action limits may be estimates



Generated By: Ryan Bellone  
 Commercial Director  
 Date: 11/13/2025



Tested By: Kelsey Rogers  
 Scientist  
 Date: 10/28/2025



## Flying Monkey Live Resin - Rainbow Mystery 2.5g Disposable

Sample ID: SA-251021-71193

Batch: BATCH: #FMV5LR25-01 | EXP: 10/30/2027

Type: Finished Product - Inhalable

Matrix: Concentrate - Vape

Unit Mass (g):

Received: 10/22/2025

Completed: 11/10/2025

**Client**

Lost Distribution

8 The Green, Suite A

Dover, DE 19901

USA

## Reporting Limit Appendix

### Heavy Metals - KY 902 KAR 45:190

| Analyte | Limit (ppm) | Analyte | Limit (ppm) |
|---------|-------------|---------|-------------|
| Arsenic | 1.5         | Lead    | 0.5         |
| Cadmium | 0.5         | Mercury | 1.5         |

### Microbials -

| Analyte                              | Limit (CFU/g) | Analyte             | Limit (CFU/g) |
|--------------------------------------|---------------|---------------------|---------------|
| Total coliforms                      | 100           | Total aerobic count | 10000         |
| Bile-tolerant gram-negative bacteria | 1000          |                     |               |
| Total yeast and mold count (TYMC)    | 1000          |                     |               |

### Residual Solvents - USP 467

| Analyte               | Limit (ppm) | Analyte                  | Limit (ppm) |
|-----------------------|-------------|--------------------------|-------------|
| Acetone               | 5000        | Ethylene Oxide           | 1           |
| Acetonitrile          | 410         | Heptane                  | 5000        |
| Benzene               | 2           | n-Hexane                 | 290         |
| Butane                | 5000        | Isobutane                | 5000        |
| 1-Butanol             | 5000        | Isopropyl Acetate        | 5000        |
| 2-Butanol             | 5000        | Isopropyl Alcohol        | 5000        |
| 2-Butanone            | 5000        | Isopropylbenzene         | 5000        |
| Chloroform            | 60          | Methanol                 | 3000        |
| Cyclohexane           | 3880        | 2-Methylbutane           | 290         |
| 1,2-Dichloroethane    | 5           | Methylene Chloride       | 600         |
| 1,2-Dimethoxyethane   | 100         | 2-Methylpentane          | 290         |
| Dimethyl Sulfoxide    | 5000        | 3-Methylpentane          | 290         |
| N,N-Dimethylacetamide | 1090        | n-Pentane                | 5000        |
| 2,2-Dimethylbutane    | 290         | 1-Pentanol               | 5000        |
| 2,3-Dimethylbutane    | 290         | n-Propane                | 5000        |
| N,N-Dimethylformamide | 880         | 1-Propanol               | 5000        |
| 2,2-Dimethylpropane   | 5000        | Pyridine                 | 200         |
| 1,4-Dioxane           | 380         | Tetrahydrofuran          | 720         |
| Ethanol               | 5000        | Toluene                  | 890         |
| 2-Ethoxyethanol       | 160         | Trichloroethylene        | 80          |
| Ethyl Acetate         | 5000        | Xylenes (o-, m-, and p-) | 2170        |
| Ethyl Ether           | 5000        |                          |             |
| Ethylbenzene          | 70          |                          |             |

### Pesticides - CA DCC

| Analyte              | Limit (ppb) | Analyte                 | Limit (ppb) |
|----------------------|-------------|-------------------------|-------------|
| Abamectin            | 300         | Hexythiazox             | 2000        |
| Acephate             | 5000        | Imazalil                | 30          |
| Acetamiprid          | 5000        | Imidacloprid            | 3000        |
| Aldicarb             | 30          | Kresoxim methyl         | 1000        |
| Azoxystrobin         | 40000       | Malathion               | 5000        |
| Bifenazate           | 5000        | Metaxyl                 | 15000       |
| Bifenthrin           | 500         | Methiocarb              | 30          |
| Boscalid             | 10000       | Methomyl                | 100         |
| Captan               | 5000        | Mevinphos               | 30          |
| Carbaryl             | 500         | Myclobutanil            | 9000        |
| Carbofuran           | 30          | Naled                   | 500         |
| Chloranthraniliprole | 40000       | Oxamyl                  | 200         |
| Chlordane            | 30          | Paclobutrazol           | 30          |
| Chlorfenapyr         | 30          | Parathion methyl        | 30          |
| Chlorpyrifos         | 30          | Pentachloronitrobenzene | 200         |
| Clofentezine         | 500         | Permethrin              | 20000       |
| Coumaphos            | 30          | Phosmet                 | 200         |
| Cyfluthrin           | 1000        | Piperonyl Butoxide      | 8000        |
| Daminozide           | 30          | Prallethrin             | 400         |
| Diazinon             | 200         | Propiconazole           | 20000       |
| Dichlorvos           | 30          | Propoxur                | 30          |
| Dimethoate           | 30          | Pyrethrins              | 1000        |
| Dimethomorph         | 20000       | Pyridaben               | 3000        |
| Ethoprophos          | 30          | Spinetoram              | 3000        |
| Etofenprox           | 30          | Spinosad                | 3000        |
| Etoxazole            | 1500        | Spiromesifen            | 12000       |
| Fenhexamid           | 10000       | Spirotetramat           | 13000       |
| Fenoxycarb           | 30          | Spiroxamine             | 30          |
| Fenpyroximate        | 2000        | Tebuconazole            | 2000        |
| Fipronil             | 30          | Thiacloprid             | 30          |
| Fonicamid            | 2000        | Thiamethoxam            | 4500        |
| Fludioxonil          | 30000       | Trifloxystrobin         | 30000       |

### Mycotoxins - Colorado CDPHE

| Analyte      | Limit (ppb) | Analyte | Limit (ppb) |
|--------------|-------------|---------|-------------|
| B1           | 5           | B2      | 5           |
| Ochratoxin A | 5           | G2      | 5           |

